

# Squeeeeeek No More®



Step 1. **Locate the floor joist, using the Joist finding screw provided. Then, push the Alignment and Depth Control Fixture firmly into the carpet.**



Step 2. **Place your weight around the fixture, and drive the scored screw down as far as the fixture will allow it to go.**



Step 3. **Place the screw gripper, on the alignment fixture over the screw head, then rock the fixture left to right snapping the head off. The screw breaks at the weak spot that is consistently just below the surface of the floor.**



**The screw stops the movement and squeaks with no damage to the carpet.**

**The Squeeeeeek No More kit includes.**  
50-Specially scored waxed screws  
Alignment and Depth control Fixture  
Driver Bit  
Joist Finder  
Complete instructions.